

How to use...

200ml DuoSyringe Systems



Description

The DuoSyringe system enables resin and hardener components to be mixed and dispensed accurately and reliably.

Instructions

1. Unscrew retaining nut fully without removing the steel disc (thus removing the green nose plug).
2. Remove steel disc from nose plug.
3. Attach mixing nozzle to the cartridge and replace retaining nut to secure.
4. Insert DuoSyringe assembly into applicator.
5. Dispense material by pulling trigger as required.

Guidance Notes

- 200ml DuoSyringe systems are identified by their part numbers. The part number will include "DS-200".
- If material is left in the mixer nozzle for longer than the work life described on the Technical Data Sheet, a new mixer nozzle should be attached.
- To reseal the cartridge either leave the nozzle attached allowing the cured adhesive to create its own seal or remove mixer nozzle and replace nose plug and nut.
- If using the cap to reseal the cartridge, ensure it is replaced as removed to avoid cross-contamination.
- Whilst every effort is made, the DuoSyringe pistons may not be level and the first 5-10ml of material should be discarded.

Issue 2 - April 2005

Resintech Limited

Horcott Industrial Estate, Fairford, Gloucestershire, GL7 4BX, United Kingdom

t: +44 (0)1285 712755 f: +44 (0)1285 712999 e: technical@resintech.co.uk w: www.resintech.co.uk